

## Software update via USB drive from PLC

- 1) Always take a picture of the values in the service menu parameters 1 and parameters 2!! (Password to service level 2, Where you can find parameters 2 is 4567). At the end You will have to restart the machine and check these parameters, If they are the same as before.
- 2) Create folder on USB drive Teco\Update\“New software file“
- 3) Uncover right leg
- 4) Plug USB Drive into the PLC



- 5) When you press arrow down, then you will see software version and time, when the software was made



- 6) When you press arrow down once more, than you will see notice, that PLC stops and upload new software



- 7) Last step is that you have to confirm it and then machine starts update



- 8) After 15-30 sec, you will have machine updated



- 9) At the end you will see on PLC screen basic information about device
- First line – PLC name for TecoRoute (Pan 31 – single pan, Pan 32 – double pan, Pan 32S – DS machine)
  - Second line – program version and date of generated program
  - Third line – serial number
  - Fourth line – language

